

反面

正面

AX1800 双频Wi-Fi6无线路由器

快速安装指南

型号:LV-AX02 VER1.0

### 1 硬件描述

端口和按键:

① 指示灯	路由器状态指示
② LAN 1-2 接口	连接电脑
③ WAN (互联网)接口	连接ADSL猫或者外网
④ 电源(DC-IN)插孔	连接电源
⑤ 复位按钮	按键5s以上系统恢复出厂设置

指示灯工作情况:

名称	状态	说明
系统灯	橙色亮	系统正在启动
	白色快闪	系统恢复出厂设置
	不亮	系统异常
	白色常亮	WAN获取到地址
	白色慢闪	WAN未获取到地址
WAN	常亮	插入网线
	闪烁	数据流通过
	不亮	未插入网线或WAN/LAN口异常
LAN1-2	常亮	插入网线
	闪烁	数据流通过
	不亮	未插入网线或WAN/LAN口异常

### 快速设置

#### 1 准备调制解调器

A. 拔出您的电缆/DSL调制解调器电源, 若调制解调器内涵备用电池, 请移除电池。

B. 使用网线连接您的调制解调器与无线路由器。

C. 开启您的电缆/DSL调制解调器。

D. 检查您的电缆/DSL调制解调器指示灯, 确认连接至网络。

#### 2 连接您的无线路由器

A. 有线连接: 将您的无线路由器连接电源并开机, 将网线的两端分别插入电脑的网口与无线路由器的LAN口。

B. 无线连接: 将您的无线路由器连接电源并开机, 用笔记本电脑或者手机连接路由器底部标签上注明的网络名称(SSID)。

#### 3 配置您的无线路由器

A. 打开电脑或者手机的浏览器, 输入<http://192.168.7.1> 或者 <http://wifi6.pix-link.net> 进入路由器的设置界面。

B. 按照路由器的设置向导完成设置, 设置完成后请记住您的无线设置和管理密码。

**注意:** 若您使用PPPOE连接互联网, 需要向您的网络服务商(ISP)取得账号和密码, 以正确设置您的无线路由器。

LV-AX02

Quick Installation Guide

Model:LV-AX02 VER1.0

### 1 Hardware Description

Ports、Button

① Indicator LED	Router status indicator
② LAN 1-2 interface	Connect the computer
③ WAN(Internet) interface	Connect to ADSL cat or outer net
④ Power supply (DC-in) jack	Connect the power supply
⑤ Reset button	Press 5s or above to restore factory Settings

LED Description

LED	Status	Indication
System lamp	Orange on	System is starting
	White fast blinking	Reset factory default
	Off	System exception
	White on	WAN Get IP address
	White slow blinking	WAN IP address not obtained
WAN	On	Cable accessed
	Blinking	The port is transmitting of receiving data
	Off	The network cable is not inserted or the WAN/LAN port is abnormal
LAN1-2	On	Cable accessed
	Blinking	The port is transmitting of receiving data
	Off	The network cable is not inserted or the WAN/LAN port is abnormal

### 2 Device login

#### 1. Basic quick setting

A. Unplug your cable /DSL modem power supply, if the modem contains backup power pool, please remove the battery.

B. Use an ethernet cable to connect your modem with a wireless router.

C. Turn on your cable /DSL modem.

D. Check your cable /DSL modem Indicator light, confirm connection to network.

#### 2 Connect to your wireless router

A. Wired connection: Connect your wireless router to the power supply and turn it on, plug the two ends of the network cable into the computer's network port and the wireless router's LAN port.

B. Wireless connection: Connect your wireless router to the power supply and turn it on, and use a laptop or mobile phone to connect to the network name (SSID) indicated on the label on the bottom of the router.

#### 3 Configure your wireless router

A. Open the browser on your computer or phone and type <http://192.168.7.1> or <http://wifi6.pix-link.net> enter the settings screen of the router.

B. Follow the router 's setup wizard to complete the setup. After the setup is complete, please remember your wireless settings and management password.

**Note:** If you are using PPPOE to connect to the Internet, you will need to contact your ISP(ISP) get the account and password to set up your wireless router correctly.